



# Time Delay Programming Instructions

- 1** Push and hold button until LED flashes rapidly (approximately 6 seconds). Release button.
- 2** Press button twice to enter Time Delay adjustment mode. The LED will flash back the current Time Delay setting according to below table (i.e. 5 flashes for 10 minute Time Delay).
- 3** Wait approximately 3 seconds
- 4** Press button the number of times for the desired setting (i.e., press twice for 2.5 minutes Time Delay).
- 5** LED will flash back this new setting, (repeated up to 10 times).
- 6** Press button down again until LED flashes rapidly (approximately 6 seconds). Release button.
- 7** Press button twice to verify Time Delay has been reprogrammed.
- 8** LED will flash back twice indicating acceptance of new setting

## Time Delay Settings Table

Push Button the number of increments desired

<b>1</b> ~ 30 Sec	<b>4</b> ~ 7.5 Min	<b>7</b> ~ 15.0 Min
<b>2</b> ~ 2.5 Min	<b>5</b> ~ 10.0 Min*	<b>8</b> ~ 17.5 Min
<b>3</b> ~ 5.0 Min	<b>6</b> ~ 12.5 Min	<b>9</b> ~ 20.0 Min